Install Beeprt Driver on Mac

Plug in the U-disk (in the package) to your computer,(or please click this link to download driver) find the file “BY-426/BY-426BT/BY-480/BY-480BT Driver_for_MacOS” and install it.

a. Follow the guide to install the printer.



b. Follow the installation steps until you receive the "The installation was successful" message and click "Close".



c. Open the "System Preferences" and click on the "Printers and Scanners."

d. In the next window, press the "+"

e. Click on Thermal Label Printer, and then choose "Select Software" in the drop-down menu.



f. Please search/find "label printer " and click OK.



g. Click on "Add", now the printer driver has been installed in your Mac book successful.


Add
Default
IP
Windows
Search
Search
Name
Kind
Beeprt BY-480BT
USB
Name:
Beeprt BY-480BT
Location:
王卫的MacBook Pro
Use:
Beeprt BY-426 Label
Add


Printers & Scanners
Search
Beeprt BY-480BT
Idle, Last Used
Thermal Label Printer
Open Print Queue...
Options & Supplies...
Location: 王卫的MacBook Pro
Kind: Beeprt BY-426 Label
Status: Idle
Share this printer on the network
Sharing Preferences...
Default printer: Last Printer Used
Default paper size: US Letter